



E003:

Refrigerators and freezers

PQS code:	E003/108
Type of appliance:	Solar direct drive refrigerator
Manufacturer's reference:	VLS 154A SDD Greenline
Manufactured in:	Denmark
Company:	Vestfrost Solutions
Address:	A/S Vestfrost Falkevej 12 DK-6705 Esbjerg Ø Denmark

Telephone: +45 7914 2555; +45 7914 2248

Email: clc@vestfrostsolutions.com

Web address: <http://vestfrostsolutions.com/>

Specifications

Climate zone:	Hot	Min rated ambient temp:	+5°C
Refrigerant:	R600a	Energy source:	Solar direct drive
Appliance tested at:	+43°C	Ext dimensions (HxLxD)	86.0 x 127.0 x 70.0 cm
Performance at:	+43°C	Fuel and cycle type:	Electric - compression
SOLAR DIRECT DRIVE REFRIGERATOR		AND / OR FREEZER	Freeze protection: Grade A
Vaccine storage capacity: (Liters)	170	Gross volume (Liters):	N/A
Gross volume (Liters):	248	Waterpack freezing capacity:	N/A
		Waterpack storage capacity:	N/A
Autonomy as per WHO/PQS protocols	73.4 hours	At a solar radiation reference period of:	3.5 kWh/m2/day

Warning !

For solar direct drive units, the correct sizing of the solar panel array for a specific site is complex and critical. It must be agreed with both the appliance manufacturer and with the Qualified Supplier of the solar energy system at the time of ordering.

<p>Prices include Vestfrost Solutions SDD PV energy kit comprising of PV panels, roof adjustable bracket system, plug & play installation. Unit equipped with unique QR code that can be used with Vestfrost Solutions Unit tracker APP, containing various installation/service features.</p> <p>As an option the appliance can be supplied with Vestfrost in-built RTMD; with following features: 1: 5" touch display 2: 3X internal temp. sensors 3: ambient temp. 4: compressor sensor 5: humidity sensor 6: lid opening alarm 7: GPS coordinates via Google maps 8: 1X USB 5V solar harvesting port. All data collected/logged is automatic via GPRS uploaded to Vestfrost RTMD performance data-portal, and/or can be accessed onsite from the touch screen menu.</p>			
Comments:			
Accessories:			
4 x Vaccine storage top basket; Bottom grating; 30 day electronic temperature logger; Self-regulating temperature control; Electronic temperature reading; 2 x Keys; Instruction manual in 6 UN languages; Technical manual in 6 UN languages; Plywood packing/crate			
Spare parts (ref, price):			
Included in the UNICEF Supply Division spare parts kit: 1 No. Compressor (BD 35K) Complete R600a Incl. ECU - Part No. 8-036510223 1 No. Thermostat - Part No. 702090044 1 No. Fan Set (KD1208PTB3) 12 V DC Part No. 7090486 1 No. Thermometer, solar, Part No.7020382-03 Other parts are available as spares on request.			
Shipping volume:		Shipping weight:	
0.83m3		108kg	
Price year		Incoterms	
2016		FCA	
Price			
1-99 units: 4,345 €		100-199 units: 4044 €	
200 or more units: 3.985 €			
Quality standard:		Specification ref.	
- ISO 9001:2008 - ISO 14001 - DS/OHSAS 18001:2008 -			
Verification report:		Verification laboratory:	
300-KLAB-15-115		Danish Technological Institute	
Current PQS status:			
<i>pre-qualified: 02 Oct 2019</i>		Validity until: <i>December 2025</i>	
Note: If Current PQS status is 'Suspended' or 'Withdrawn', this product is NOT to be purchased.			