



E003:

Refrigerators and freezers

PQS code:	E003/108
Type of appliance:	Solar direct drive refrigerator
Manufacturer's reference:	VLS 154A SDD Greenline
Manufactured in:	Denmark
Company:	Vestfrost Solutions
Address:	A/S Vestfrost Falkevej 12 DK-6705 Esbjerg Ø Denmark
Telephone:	+45 7914 2555; +45 7914 2248
Email:	clc@vestfrostsolutions.com ; bjn@vestfrostsolutions.com
Web address:	http://vestfrostsolutions.com/

Specifications

Climate zone:	Hot	Min rated ambient temp:	+5°C
Refrigerant:	R600a	Energy source:	Solar direct drive
Appliance tested at:	+43°C	Ext dimensions (HxLxD)	86.0 x 127.0 x 70.0 cm
Performance at:	+43°C	Fuel and cycle type:	Electric - compression
SOLAR DIRECT DRIVE REFRIGERATOR AND / OR FREEZER			Freeze protection: Grade A
Vaccine storage capacity: (Liters)	170	Gross volume (Liters):	N/A
Gross volume (Liters):	248	Waterpack freezing capacity:	N/A
		Waterpack storage capacity:	N/A
Autonomy as per WHO/PQS protocols	73.4 hours	At a solar radiation reference period of:	3.5 kWh/m ² /day

Warning !

For solar direct drive units, the correct sizing of the solar panel array for a specific site is complex and critical. It must be agreed with both the appliance manufacturer and with the Qualified Supplier of the solar energy system at the time of ordering.

Prices include Vestfrost Solutions SDD PV energy kit comprising of PV panels, roof adjustable bracket system, plug & play installation.
Unit equipped with unique QR code that can be used with Vestfrost Solutions Unit tracker APP, containing various installation/service features.

As an option the appliance can be supplied with Vestfrost in-built RTMD; with following features:
1: 5" touch display 2: 3X internal temp. sensors 3: ambient temp. 4: compressor sensor 5: humidity sensor 6: lid opening alarm 7: GPS coordinates via Google maps 8: 1X USB 5V solar harvesting port. All data collected/logged is automatic via GPRS uploaded to Vestfrost RTMD performance data-portal, and/or can be accessed onsite from the touch screen menu.

Comments:

Accessories:

4 x Vaccine storage top basket; Bottom grating; 30 day electronic temperature logger; Self-regulating temperature control; Electronic temperature reading; 2 x Keys; Instruction manual in 6 UN languages; Technical manual in 6 UN languages; Plywood packing/crate

Spare parts (ref, price):

Included in the UNICEF Supply Division spare parts kit:
1 No. Compressor (BD 35K) Complete R600a Incl. ECU - Part No. 8-036510223
1 No. Thermostat - Part No. 702090044
1 No. Fan Set (KD1208PTB3) 12 V DC Part No. 7090486
1 No. Thermometer, solar, Part No.7020382-03
Other parts are available as spares on request.

Shipping volume:	0.83m3	Shipping weight:	108kg
-------------------------	--------	-------------------------	-------

Price year	2016	Incoterms	FCA
-------------------	------	------------------	-----

Price

Quality standard:	- ISO 9001:2008 - ISO 14001 - DS/OHSAS 18001:2008 -	Specification ref.	
--------------------------	--	---------------------------	--

Verification report:	300-KLAB-15-115	Verification laboratory:	Danish Technological Institute
-----------------------------	-----------------	---------------------------------	--------------------------------

Current PQS status:	<i>pre-qualified: 02 Oct 2019</i>	Validity until:	<i>May 2025</i>
----------------------------	-----------------------------------	------------------------	-----------------

Note: If Current PQS status is 'Suspended' or 'Withdrawn', this product is NOT to be purchased.